


ENGLISH Key Features and Parts

The headset contains the following parts:

Using Finger Tip Controls

The surface of the right ear cup is a touch sensitive control surface. The center section (the logo) serves as a play/pause control. Tap once for play/pause also for answer/end.



Headset Controls

ACTION ON TOUCH PAD	FUNCTION
Hold for 2 sec.	voice dial when no call is in progress / reject call / *switch call between phone and headset / *reject call waiting
tap x1	answer call/end call / *accept call waiting
tap x2	track forward / *accept call on hold
tap x3	track back
Hold Touch Pad and Multifunction button for 2 sec.	redial
Double press Multifunction Button	*mute/unmute microphone

*Action during call.

Pairing

- Ensure that your phone or music player is switched on.
- To pair the headset if it **has not** been previously paired with a device, **switch on** the headset, it will enter the pairing mode automatically and the blue and red indicator light starts to flash quickly. The headset is ready to pair with your device.
- To pair the headset if it **has been** previously paired with another device, ensure that the headset is **switched off**, and press and hold the multifunction key (for about five seconds) until the blue and red indicator light starts to flash quickly.
- Activate the Bluetooth feature on your phone or music player, and set it to search for Bluetooth devices.
- Select **"FREEDOM"** from the list of found devices on your phone or music player.

Guide to Indicator Lights

INDICATOR LIGHT	DESCRIPTION
Red flash x2	Connectable
Blue and red alternate flash	Connectable/Discoverable
Blue flash x1	<ul style="list-style-type: none"> • Connected • Outgoing Call Establish • Incoming Call Establish • Active Call • TWC Call Waiting • Active Call no SCO • Streaming A2DP
Red flash x1	<ul style="list-style-type: none"> • TWC Call On Hold • TWC Multi Party Call

No Batteries Required

You can use your FREEDOM On-Ear headphone as a wired headphone to save batteries or if your batteries are not charged.

Disconnect the Headphone

To disconnect the headset from your device, switch off the headset, or disconnect it in the *Bluetooth* menu of your device.

Reconnect the Headphone


To connect the headset to the phone or music player that you last used with it, switch on the headset or make the connection in the *Bluetooth* menu of your device.

FRANÇAIS Caractéristiques et pièces principales

Le casque d'écoute est doté des pièces et caractéristiques suivantes :

Utilisation des commandes tactiles

La surface de l'oreillette droite est une surface de commande tactile. La section centrale (le logo) sert de commande de lecture/pause. Touchez-la une fois pour faire jouer une piste ou en interrompre la lecture, ou pour répondre à un appel ou y mettre fin.



Commandes de l'oreillette

ACTION SUR LE PAVÉ TACTILE	FONCTION
Appuyer pendant 2 s	Composition vocale quand aucun appel n'est en cours / Rejeter un appel / *Refuser la mise en attente / *Transférer l'appel du téléphone aux écouteurs
Toucher 1 fois	Répondre/mettre fin à un appel / * Accepter la mise en attente
Toucher 2 fois	piste suivante / * Accepter l'appel en attente
Toucher 3 fois	piste précédente
Tenir enfoncés le pavé tactile et le bouton multifonction pendant 2 s	Recomposer
Appuyer deux fois sur le bouton multifonction	*Désactiver/activer le son du microphone

* À faire pendant un appel

Synchronisation

- Assurez-vous que votre téléphone ou votre lecteur de musique est en marche.
- Pour synchroniser les écouteurs s'ils n'ont pas encore été synchronisés à un appareil, mettez-les en marche. Ils passeront automatiquement en mode de synchronisation, et les témoins bleu et rouge clignoteront rapidement. Les écouteurs sont alors prêts à être synchronisés avec votre appareil.
- Pour synchroniser votre casque s'il a déjà été synchronisé avec un autre appareil, éteignez-le et maintenez la touche multifonction enfoncée pendant environ 5 secondes jusqu'à ce que le témoin bleu et rouge se mette à clignoter rapidement.
- Activez la fonction Bluetooth sur votre téléphone ou votre lecteur de musique, et réglez-la pour qu'elle recherche des appareils Bluetooth.
- Sélectionnez « **FREEDOM** » dans la liste des appareils détectés par votre téléphone ou votre lecteur de musique.

Guide Des Témoins Lumineux

TÉMOIN LUMINEUX	DESCRIPTION
Le témoin rouge clignote 2 fois	Connectable
Les témoins bleu et rouge clignent en alternance	Connectable/découvrable
Le témoin bleu clignote 1 fois	<ul style="list-style-type: none"> • Connecté • Appel sortant établi • Appel entrant établi • Appel en cours • Appel en attente TWC • Appel en cours sans SCO • Distribution audio avancée (A2DP) en continu
Le témoin rouge clignote 1 fois	<ul style="list-style-type: none"> • Appel en attente TWC • Appel conférence TWC

Aucune pile nécessaire

Vous pouvez utiliser vos écouteurs FREEDOM On-Ear comme des écouteurs avec fil pour ménager les piles ou si celles-ci ne sont pas chargées.

Déconnexion des écouteurs

Pour déconnecter le casque de votre appareil, éteignez le casque ou déconnectez-le dans le menu Bluetooth de votre appareil.

Reconnexion des écouteurs

Pour reconnecter le casque au dernier appareil utilisé (téléphone ou lecteur de musique), mettez le casque en marche ou connectez-le dans le menu Bluetooth de votre appareil.



CE DECLARATION OF CONFORMITY

We, **Monster LLC**, 455 Valley Dr., Brisbane, CA 94005, USA declare under the sole responsibility that the product:

Model: 190677

Kind of equipment: Headphone On Ear Bluetooth

Complies with the essential requirements of Article 3 of the R&TTE 1999/5/EC Directive, if used for its intended use and that the following standards have been applied:

1. Directive 1999/5/EC (R&TTE Directive).
EN 300 328 V1.9.1 (2015-02)
EN 62479:2010
2. EMC Directive 2004/108/EC:
EN 55013:2013
EN 55020:2007+ A11:2011
ETSI EN 300 328-1 V1.9.2 (2011-09)
ETSI EN 301 489-17 V2.2.1 (2012-09)
3. HEALTH and SAFETY - LVD Directive 2006/95/EC
EN60065:2002+A1:2006+A11:2008+A2:2010+A11:2011
4. Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment, and it has been demonstrated that the requirements specified in Article 4 of such Directive have been met.
5. Products do not contain any of the REACH Substances of Very High Concern (SVCH) according to the Candidate list published by ECHA (European Chemical Agency)

CE mark first affixed in September 2016.

Technical documentation, TCF, relevant to the above equipment is held at:

Monster LLC.

Authorized Person: Aida Krajisnik, Corporate QA and Compliance Manager
Email: ProductCompliance@monstercable.com
Telephone No.: (415) 330-4439


Signature:

